

BOA PAR 180

A001	d001			
8ch	8ch			
1	1	0	255	Master dimmer
2	5	0	255	Red
3	6	0	255	Green
4	7	0	255	Blue
5	8	0	255	White
6	2			Strobe
		0	4	Strobe off
		5	255	Strobe min-max
7	3			Mode
		0	0	No function
		1	62	Fixed colour
		63	124	Auto color jump
		125	186	Auto color fade
		187	249	Auto color pulse
		250	255	Sound mode
8	4			Function
		<i>*Mode channel 1~62 (fixed colour select)</i>		
		0	16	Red
		17	38	Green
		39	50	Blue
		51	67	White
		68	84	Yellow
		85	101	Magenta
		102	118	Light red
		119	135	Cyan
		136	152	Light green
		153	169	Light blue
		170	186	White (RGB)
		187	203	Light yellow
		204	220	Light magenta
		221	237	Light cyan
		238	255	White (RGBW)
		<i>*Mode channel 63~249 (auto speed)</i>		
		0	255	Speed slow to fast
		<i>*Mode channel 250~255 (sound mode)</i>		
		0	15	Red
		16	31	Green
		32	47	Blue
		48	63	White
		64	79	Yellow
		80	95	Magenta
		96	111	Light red
		112	127	Cyan

		128	143	Light green
		144	159	Light blue
		160	175	White (RGB)
		176	191	Light yellow
		192	207	Light magenta
		208	223	Light cyan
		224	239	White (RGBW)
		240	255	Auto color jump